



Well Shocking

****BEST TO DO THIS IN THE EVENING RIGHT BEFORE BEDTIME****

****IF YOU HAVE WATER FILTRATION EQUIPMENT, YOU MUST PUT ALL OF IT IN BYPASS DURING THIS PROCESS OR YOU WILL RUIN THE MEDIA!!****

1. Put ½-1 gallon of chlorox bleach (non-scented) for every 100' of depth of the well straight down the well casing.
2. Get a garden hose, attach one end to the outside silcock closest to the well, the other end of the hose put directly into the well casing
3. Turn the water on and let it cycle for about 2-3 hours
4. Shut the spigot off
5. Go in the house and one by one turn each faucet on just until you smell chlorine, even do the bathtub and the hot water. Once you smell the chlorine shut the faucet off, let it sit overnight.
6. In the morning, run the garden hose into the woods and let the water run for about 30 minutes, this will flush most of the chlorine out. **You do not want to run the faucets in the house with this much chlorine, it will go right into the septic which isn't recommended.** After 30 minutes, you can run each faucet until this smell dissipates. At this time you can turn the filtration equipment back online. You will still have some chlorine smell, but not a lot.

****Any questions...don't hesitate to call!**